

# ***How to use the HEX Code data (.pcf file)***

**Category** :

**Document Version** : **1.00**

**Author(s)** : ***Marantz America, Inc.***

**Date** : **October 28, 2009**


**Number of Page** : **34**

## 1. Introduction ~ Download ~ Install

This configuration file contains Marantz RC5x IR Receiver codes which have been converted to HEX (Pronto Style) format.

To access these codes go to the RC9500 Remote Control page under Manuals & Downloads, download and install the Wizz.it 9 editor. (You do not need a remote control)


Please visit Marantz Support website, <http://us.marantz.com/136.asp>



1. Select "Remote Controls"

2. Select "RC9500"

3. Click "GO"



1. Click "RC9500 Wizz.it 9 Editor"


2. Save it in your PC

- Extract

“Wizz.it\_9\_V2\_Setup.zip” which you downloaded. “Wizz.it 9 V2 Setup.exe” will be appeared.

- Before Install

If you install this to Windows Vista/7, it required 32bit version. It doesn't work with 64bit version. Set to Windows XP mode like as following procedure example.




- Install


Please install “Wizz.it 9 V2 Setup.exe” as general software.

## 2. Pick up Hex code from .pcf file


Open the configuration file (e.g. RC9500 Marantz AVR – HEX IR.pcf) by double click, Wizz it 9 will start and the pcf file be opened in the program window.



Click “+” to expand page list.




Select the page of commands you need and double click it.





The Page panel will be opened.

Double click the command (button) you need.

The "Button Properties" window will open.




The HEX code window (Add IR Code) window will open over the "Button Properties".



1. Right Click on "IR Code:" window

2. Select "Select All" from the pull down menu. and click.

Right click and copy the hex code.



Now the HEX code is stored in "Clip Board". You can paste it to your favorite place.  
This is an example of Excel spread sheet.

Microsoft Excel - Book1

ファイル(E) 編集(E) 表示(V) 挿入(I) 書式(O) ツール(T) データ(D) ウィンドウ(W) ヘルプ(H)

校閲結果の返信(C)... 校閲結果の差し戻し(R)...

	A	B	C
1		0000 0071 0000 0024 0020 0020 0020 0020 0020 0020 0040 0020 0020 0020 0020 0020 0020 00A0 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0020 0040 0040 0020 0AAB 0020 0020 0020 0020 0020 0020 0040 0020 0020 0020 0020 0020 0020 00A0 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0020 0040 0040 0020 04B0	
2			
3			
4			

Please do same process repeatedly for all codes you need.