

Tip: RC101 Quick Reference

Ref #: 070511-02



1. **Change the Zone**
 - a. Press and Hold **SET** and **ZONE** buttons until **SEND** indicator blinks twice
 - b. Press: **A** for **Zone-A(2)** control (SR-5005,SR-6005,SR-7005)
B for **Zone-B(3)** control (SR-7005)
D for **Main-zone** control
2. **Control Multi-speaker On/Off**
 - a. Press and Hold **SET** and **POWER ON** buttons until **SEND** indicator blinks twice
 - b. Press: **2** for **Multi-Speaker** control
1 for **Multi-Room** control
 - c. Press: **ENTER**
3. **Turn the Backlight OFF**
 - a. Press and Hold **SET** and **⏪** buttons until backlight turns off
4. **Turn the Backlight ON**
 - a. Press and Hold **SET** and **⏩** buttons until backlight turns on
5. **Learn the Command**
 - a. Press and Hold **SET** and **MENU/INPUT** buttons until **LEARN** indicator blinks
 - b. Press **One of Source** button which you like to learn the command (**LEARN** indicator blinks)
 - c. Press the **Button** to be learned (LEARN indicator lights up)
 - d. Aim the original remote to the front of RC101
 - e. Press and Hold the button on the original remote until **SEND** indicator blinks twice
 - f. Repeat the step **c** and **e**
 - g. Press **SET** button to complete
6. **Change the Pre-code setting**
 - a. Press and Hold **SET** and **One of Source** button you would like to change until **SEND** indicator blinks twice
 - b. Type **4 digits** (You can find the 4 digits from user manual)
7. **Back to the Factory Default**
 - a. Press and Hold **SET** and **MENU/INPUT** buttons until **SEND** indicator blinks twice
 - b. Press and Hold **SLEEP**, **POWER ON** and **POWER OFF** until **LEARN** indicator lights up
 - c. Press **ENTER** (**SEND** indicator blink twice)
 - d. Press **SET** button to complete