

Online manual | Manuel en ligne | Manual en línea



Quick Start Guide Guide de démarrage rapide


Guía de inicio rápido

marantz


GRAND HORIZON

Luxury Wireless Speaker | Haut-parleur sans fil de Luxe

1




2



3



4



EN

1. Connect to power.
2. Install the rear cover.
To avoid pinching your fingers, hold the cover by its bottom edge.
3. Download the HEOS app.
4. Select **"Add Device"** from the **"Settings menu"** to complete setup.

FR

1. Branchez à l'alimentation.
2. Installez le couvercle arrière. Pour éviter de vous pincer les doigts, tenez le couvercle par son bord inférieur.
3. Téléchargez l'application HEOS.
4. Sélectionnez **"Ajouter un périphérique"** dans le **"Menu des réglages"** pour terminer la configuration.

ES

1. Conecte a la alimentación.
2. Instale la tapa trasera. Para evitar pillarse los dedos, sujete la tapa por el borde inferior.
3. Descargue la aplicación HEOS.
4. Seleccione **"Agregar el dispositivo"** en el **"menú Ajustes"** para completar la configuración.



HEOS

