marantz®

Network Receiver M-CR510

Quick Setup Guide

Start Here
Commencez ici
Iniciar aquí

>

Before you begin

What's In The Box

M-CR510

Power cord

Remote and batteries

Product manual on CD-ROM

Required For Setup

Network router

Speakers

Speaker cables

Optional

iOS device and USB cable

Router with WPS

Network cable

* For detailed instructions or assistance, please refer to the enclosed CD-ROM manual or visit our support site: www.marantz.com

1

1. Connection

1 Connect the left and right speakers to the M-CR510

3/8 Inch (10mm)

R

L

2 Connect the power cord from the M-CR510 to a power outlet

3 Insert the batteries into the remote

2. Connecting to your home network

Choose from one of the following options

Wireless

iOS device + USB cable

**1** Power on

2 Select language

[Select Language]
♦ **English**
↕ select   ⊕ : enter

3 Make sure your iOS device is already connected to your WiFi Network then connect your iOS device to the front using your USB cable.
Note: You must be running iOS version 5 or later

No WPS router

Wi-Fi router

1 Power on

2 Select language

[Select Language]
♦ **English**
↕ select   ⊕ : enter

3 Auto scan
Please wait as your M-CR510 looks for available networks...

[Quick Setup]
Looking for wireles...
◄ : cancel

WPS router

WI-FI PROTECTED SETUP   WPS   Wi-Fi router

1 Power on

2 Select language

[Select Language]
♦ **English**
↕ select   ⊕ : enter

3 Press the WPS button on your router

WPS

Wired

1 Connect a network cable between your M-CR510 and your router
(cable not included)

NETWORK

2 Power on

3

Network Control

[Network Control]
On
Press ENTER to use the Maran...

Select Network Control ON to control M-CR510 from your smartphone, use Apple AirPlay® and maintain constant network access. Power Consumption during standby power will be slightly higher.

[Network Control]
Off
Press ENTER to use low power....

Select Network Control OFF to reduce power consumption during standby. You can not turn on your M-CR510 from your smartphone or use Apple AirPlay until your M-CR510 is powerd on manually and connects to your network.

Setup Complete!

4 Press the red Wi-Fi CONNECT Button on the back of your M-CR510

Wi-Fi Sharing

Wi-Fi CONNECT

5 This message will appear on your iOS device Select "Allow"

Share Wi-Fi Settings?
Do you want to share your Wi-fi settings so this accessory can connect to the Wi-Fi network?
Ignore   Allow

Connected!

4 Select your network name
If your network name is not listed, select "Rescan"

SSID

[Select Network]
Network(WPA2-... 100%
⊕ : enter   ◄ : back

5 Enter your network password using the number keys on the remote control

[Enter Wi-Fi Password]
A B C D
⊕1D :character type   1~9 : a

Connected!

4 Within 2 minutes, **Press and Hold** the red Wi-Fi CONNECT button on the back of your M-CR510 for 3 seconds

Wi-Fi CONNECT

5 Please wait as completing the connection can take a few minutes
The front panel of the M-CR510 will show the status of the connection

[Quick Setup]
Waiting for connect...
◄ : cancel

Connected!

3 Select language

[Select Language]
English
select   ⊕ : enter

**4** Please wait while your M-CR510 connects to your wired network.

Connected!

4

3. Enjoying your music!

Enjoying Internet radio

1 Press the "INTERNET RADIO" button on the remote

2 Select a station

- Public
- ► ■ **Popular Stations**
- Largest Cities

Enjoying music using Apple AirPlay

1 Tap the AirPlay Icon from within any app that supports AirPlay

2 Select the "Marantz M-CR510" from the AirPlay Device list

Note: Make sure your iOS device is on the same network as the M-CR510

Download the Marantz Remote App

Scan the QR code to download and install the Marantz Remote App using your smartphone and a scanning app or manually search the Apple App store or Google Play store for the "Marantz Remote App"